

## **Servo Arm Tooth Splines by Manufacturer**

To align the servo arm to the servo, try rotating the servo arm to get it 90 degrees to the control rod if your airplane design requires this alignment. A couple degrees may not make much difference.

You must use servo arms with the correct number of teeth:

23 Tooth Spline - Airtronics, JR, Spektrum

24 Tooth Spline - Hitec

25 Tooth Spline - Futaba, Savox