

To protect the sheeting I used some tape when I sanded profile in the dorsal fin.



The top is now finished. This is a good time to score some panel lines on the top because it is still flat on the table. To score I use the dull side of a tableknife. Use a piece of tape where you want the panel line and follow it with the knife. No need to press very hard, you only want to dent it, not partly cut it. My lines are semi-scale. Use the topview to determine where a line should be. It will look great even if not all lines are there or in the right place.





Cut out the vertical fin and sand some profile in it. Score rudder hingelines etc. Wait with installing until the last possible moment.



Gather all the parts for the tailerons. 2 mm pianowire, a bushing with a 2 mm inner diameter, 1mm and 3 mm balsa and some fuel tubing. Laminate the bushing between the balsa.

