

Combi Switch in DX18G2 by Andy Kunz

If you want to do AND and OR logic, you need a DX18G2/Stealth or DX18QQ.

You select a switch named "Combi" which allows you to define the combination or multiple switches and the relationship (AND or OR) between them.

The DX9 doesn't include the ability to edit the combinations.

Andy Kunz