

Flight Mode Switch Position and Active Throttle Curve Selection by Andy Kunz

Originally Posted by Deerslayer [▶](#)

I am still confused. I did get 3 Throttle Curves set up to be selected by my Flight Mode switch. At least I THINK that is what happened. Now, on the Throttle Curve screen, there is no evidence that a different Curve is being selected as I change the FM switch positions.

If you look at the boxes under the FM switch, you can see a tick mark that shows the current position of the switch. When the mark is at a blacked box, it's the active curve being shown. If it's at a hollow box, the displayed curve is not active. Change the Curve number until you see the blacked box match the tick.

Andy Kunz