

## Sounds - Combining Voice Alerts

I have the DX18gen2 with the latest voice files.

I'm using Sw. H to turn off / on the electronic ignition in a gas airplane. I'm choosing the words "Ignition" "on" and "Ignition" "off" for Sw. H.

I'm getting "Ignition No Data On" and "Ignition No Data Off" from the speaker depending on which way I flip Sw. H.

Can I get rid of the words "No Data"?

I'm not sure why they are spoken. They aren't on the Voice Alerts list along with Ignition.

If I can't fix this, I can go with "Motor Off" and "Motor On" unless someone has a suggestion.

Thanks for helping me. 😊

### **Answer:**

The problem is that you chose a voice prompt that depends on telemetry. Unfortunately, the Ignition voice command is not usable without telemetry and doesn't work the way you expect it to right now. When the custom voice prompts and their PC program comes out you'll be able to add whatever you want I assume.

I also use H for ignition, but also assign throttle cut to H, so I use 'throttle cut on/off'.

Cheers